

## Mask Set Errata for Mask 0N10D

### Introduction

This report applies to mask 0N10D for these products:

- MPC5604E

Errata ID	Errata Title
4080	Device cannot come out of reset till VDD_LV is less than a threshold value.
3864	MC_RGM: A non-monotonic ramp on the VDD_HV/BV supply can cause the RGM module to clear all flags in the DES register.

### e4080: Device cannot come out of reset till VDD\_LV is less than a threshold value.

**Errata type:** Errata

**Description:** In the external supply regulation mode of the device, if the input core supply voltage (VDD\_LV) is below the potential of 1.24V at the time of startup, the device might get stuck in reset. This high voltage is required for initial approximately 2ms. Once device comes out of reset, the core voltage can be reduced till spec voltage of 1.15V.

**Workaround:** 1. Input core voltage should be 1.24V at the time of startup. It can be lowered after device is out of reset. Device reset status is indicated by the RESET pin.

2. Operate the device in Internal supply regulation mode.

### e3864: MC\_RGM: A non-monotonic ramp on the VDD\_HV/BV supply can cause the RGM module to clear all flags in the DES register.

**Errata type:** Errata

**Description:** During power up, if there is non-monotonicity in power supply ramp with a voltage drop > 100mV due to external factors, such as battery cranking or weak board regulators, the SoC may show a no flag condition (F\_POR==LVD12==LVD27==0).

Under these situations, it is recommended that customers use a workaround to detect a POR.



In all cases, initialization of the device will complete normally.

**Workaround:** The software workaround need only be applied when neither the F\_POR, LVD27 nor LVD12 flag is set and involves checking SRAM contents and monitoring for ECC errors during this process. In all cases, an ECC error is assumed to signify a power-on reset (POR).

Three suggestions are made for software workarounds. In each case, if POR is detected all RAM should be initialized otherwise no power-on condition is detected and it is possible to initialize only needed parts of RAM while preserving required information.

Software workaround #1 :

An area of RAM can be reserved by the compiler into which a KEY, such as 0x3EC1\_9678, is written. This area can be checked at boot and if the KEY is incorrect or an ECC error occurs, POR can be assumed and the KEY should be set. Use of a KEY increases detection rate to 31 bits ( $= < 10e-9$ ) or 23bits ( $= < 5.10e-6$ ) instead of 7-bit linked to ECC ( $= < 10e-2$ )

Software workaround #2 :

When runtime data should be retained and RAM only fully re-initialized in the case of POR, a checksum should be calculated on the runtime data area after each data write. In the event of a reset where no flags are set, the checksum should be read and compared with one calculated across the data area. If reading the checksum and the runtime data area succeeds without an ECC error, and the checksums match, it is assumed that no POR occurred. The checksum could be a CRC, a CMAC or any other suitable hash.

Software workaround #3 :

Perform a read of memory space that is expected to be retained across an LVD reset. If there are no ECC errors, it can be assumed that an LVD reset occurred rather than a POR.

## How to Reach Us:

### Home Page:

[www.freescale.com](http://www.freescale.com)

### Web Support:

<http://www.freescale.com/support>

### USA/Europe or Locations Not Listed:

Freescale Semiconductor  
 Technical Information Center, EL516  
 2100 East Elliot Road  
 Tempe, Arizona 85284  
 +1-800-521-6274 or +1-480-768-2130  
[www.freescale.com/support](http://www.freescale.com/support)

### Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH  
 Technical Information Center  
 Schatzbogen 7  
 81829 Muenchen, Germany  
 +44 1296 380 456 (English)  
 +46 8 52200080 (English)  
 +49 89 92103 559 (German)  
 +33 1 69 35 48 48 (French)  
[www.freescale.com/support](http://www.freescale.com/support)

### Japan:

Freescale Semiconductor Japan Ltd.  
 Headquarters  
 ARCO Tower 15F  
 1-8-1, Shimo-Meguro, Meguro-ku,  
 Tokyo 153-0064  
 Japan  
 0120 191014 or +81 3 5437 9125  
[support.japan@freescale.com](mailto:support.japan@freescale.com)

### Asia/Pacific:

Freescale Semiconductor China Ltd.  
 Exchange Building 23F  
 No. 118 Jianguo Road  
 Chaoyang District  
 Beijing 100022  
 China  
 +86 10 5879 8000  
[support.asia@freescale.com](mailto:support.asia@freescale.com)

### For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center  
 1-800-441-2447 or +1-303-675-2140  
 Fax: +1-303-675-2150  
[LDCForFreescaleSemiconductor@hibbertgroup.com](mailto:LDCForFreescaleSemiconductor@hibbertgroup.com)

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductors products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claims alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-complaint and/or non-Pb-free counterparts. For further information, see <http://www.freescale.com> or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to <http://www.freescale.com/epp>.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© 2012 Freescale Semiconductor, Inc.

